

DIAMOND RENTAL

Parties · Tents · Events

COTTON CANDY MACHINE

Parts / Supplies	1
Requirements	2
Set-Up	3
Operation	4
Clean-Up	5
Making Floss	6
Locations	7

Volume # 2013-A
Document Property of
Diamond Rental ©

PARTS / SUPPLIES

- Base unit with Motor, Spinner Head and two (2) Leather Floaters
- Round Floss Pan
- Floss Pan Netting
- Six (6) Netting Clips
- Optional Floss Pan Bubble Cover
- Extension Cord (10-12 gauge, 50' or less)
- Cotton Candy Cones
- Sugar Floss Mix (Blue or Pink)


REQUIREMENTS

- 120 Volt / 10 Amp

SET-UP

- Level Table / Surface
- Dedicated Power Circuit within 50 Feet
- Dry Area / No Water Near the Spinner Head

MAKING FLOSS



Cotton Candy Machine
w/Floss Pan



Transport
Handle Style



Transport
Screws Style

Sample Photo / Actual Cotton Candy Machine Style May Vary.

OPERATION INSTRUCTIONS

1. Either loosen the two transportation nuts and push down to release the motor head OR pull the transport handle down if unit with large handle to release the motor head.
2. Check to make sure the spinner head has the two leather floater heads attached.
3. Place the floss pan on top of the motor.
4. Install the netting around the outer edge of the floss pan.
5. Secure the netting using the six clips.
6. Pour your Sugar Floss into the spinner on top of the motor.
7. Plug unit into power source / outlet.
8. Turn on the motor by pressing the Master button "On".
9. Adjust the heat to a lower setting and press the Heat button "On".
10. After a few minutes adjust the heat to a middle heat setting.
11. You are ready to begin!

LOCATIONS

SALT LAKE CITY
4518 South 500 West
801-262-2080

OREM
1350 Sandhill Road
801-222-9311

OGDEN
1639 South 1900 West
801-393-5353

CLEAN-UP

- When finished, run out all remaining floss until empty.
- Turn heat knob up to highest setting for 60 seconds.
- NEVER place water in the floss head.
- Unplug machine.
- Use a damp cloth to wipe off the floss head.
- Dry all parts if needed.