

# DIAMOND RENTAL

Parties · Tents · Events

## TOWABLE GRILL

Parts	1
Optional Items	2
Requirements	3
Set-Up	4
Operation	5
Clean-Up	6
Helpful Hints	7

Volume # 2013-C  
Document Property of  
Diamond Rental ©

### PARTS

- Trailer w/Two Grills
- Two Swivel Hoods
- Storage Box
- 2" Ball Hitch
- Propane Tank Harness (Two Tanks)
- Eight (8) Grill Grates (Four Per Side)
- Eight (8) Drip Sheet Pans (Four Per Side)



**FOR OUTDOOR USE ONLY!**

*Sample Photo / Actual Towable Grill Style May Vary.*

### HELPFUL HINTS

- Lower Main Grill = 16" Deep x 64" Wide
- Upper Grill Shelf = 8" Deep x 64" Wide
- 320,000 BTU's/Hr.
- Maximum 60 MPH towing speed
- Trailer Dimensions 48"W x 124"L x 62"T

### OPTIONAL ITEMS

- Propane Tanks w/Fuel
- Grill Gun / Lighter
- Grilling Spatula
- Grilling Tongs
- Grill Brush (cleaning)
- Chafer Pans
- Aluminum Foil

### REQUIREMENTS

- Propane Tank / Fuel

### SET-UP

- Level Surface
- Non-Flammable Site

### TROUBLE SHOOTING

- If you have any problems or concerns, please call your local Diamond Rental Party Location.

### CLEAN-UP

1. When finished, close all knobs.
2. Close the tank's main cylinder valve.
3. Disconnect propane tank.
4. Remove all food / pans / storage supplies.
5. Clean grill with soapy water & grill brush. A car wash can be helpful.

### OPERATION INSTRUCTIONS

1. Make sure the ball hitch latch is down and secure before towing.
2. Open the main cylinder valve and allow 2-5 minutes for the propane to fill the fuel lines.
3. Hold a lit butane gun next to a burner and turn the control knob to OPEN. The burner will ignite immediately.
4. The second burner in each section will instantly light by simply turning it on.
5. Repeat on the opposite side if desired.
6. Adjust control to the desired temperature.

### LOCATIONS

**SALT LAKE CITY**  
4518 South 500 West  
801-262-2080

**OREM**  
1350 Sandhill Road  
801-222-9311

**OGDEN**  
1639 South 1900 West  
801-393-5353